


SCK GND

TP44 TP45 R40 TP48

3V8 TP40 PWDN


SDA TP46 SCL0 47 Cam\_VDD



TP49 SD\_VDD

SD 2.0


USB\_ON/OFF



CLK2 DAT2

TP18 TP19

SIM2



RST2 VDD2 TP20 TP17 Q3

